



**New & Used Sportbike Parts, Accessories
& Apparel**



www.pprcycles.com or (803) 786-2990

BIKE	Description	QTY	OEM #	Used/ New
Yamaha 94-96 TZ 125	94 Cylinder 4JT1	1		USED
Yamaha 94-96 TZ 125	94 Wiring harness	1	4JT-82590-00	USED
Yamaha 94-96 TZ 125	96 CDI 4JT-20	1		USED
Yamaha 94-96 TZ 125	96 Cylinder 4DP-11	1		USED
Yamaha 94-96 TZ 125	Air Box	1	9411-29m-n	USED
Yamaha 94-96 TZ 125	Axle, Drive	2	4JT-17421-00	USED
Yamaha 94-96 TZ 125	Axle, Front	1	4JT-25436-10-A	USED
Yamaha 94-96 TZ 125	Axle, Main 1st	2	4JT-17411-00	USED
Yamaha 94-96 TZ 125	Axle, Rear	2	4JT-25381-00	USED
Yamaha 94-96 TZ 125	6 Fork Springs & 2 Set Valve Bodies	1		USED
Yamaha 94-96 TZ 125	Bag of Misc. fasteners, shims, bolts	1		USED
Yamaha 94-96 TZ 125	Balance Shaft 1 w/ Weight	2	4JT-11455-00	1 New / 1 Used
Yamaha 94-96 TZ 125	Ball 5/16th	11	93505-16006	NEW
Yamaha 94-96 TZ 125	Bar, Shift Fork Guide 1	2	4JT-18531-00	USED
Yamaha 94-96 TZ 125	Bar, Shift Fork Guide 2	2	4JT-18535-00	USED
Yamaha 94-96 TZ 125	Base Gasket	3	4DP-11351-20	NEW
Yamaha 94-96 TZ 125	Base Gasket, Cylinder (.7)	2	4JT-11351-12	NEW
Yamaha 94-96 TZ 125	Bearing	1	93306-30316	NEW
Yamaha 94-96 TZ 125	Bearing 95 TZ -	1	93306-90105	NEW
Yamaha 94-96 TZ 125	Bearing Crank	2	93306-30566	NEW
Yamaha 94-96 TZ 125	Bearing Cylindrical	1	93310-52403	NEW
Yamaha 94-96 TZ 125	Bearing Rod Big End	3	93310-225N0	NEW
Yamaha 94-96 TZ 125	Bearing, Piston Small End Cylinder	4	93310-316D5	NEW
Yamaha 94-96 TZ 125	Bolt Flange	6	95817-06040	NEW
Yamaha 94-96 TZ 125	Brake Pedal	2	4JT-27211-00	1 New / 1 Used
Yamaha 94-96 TZ 125	BREMBO Brake Caliper -Front	1	4TW-25804-00	USED
Yamaha 94-96 TZ 125	BREMBO front brake lever	1	4JT-83922-00	NEW
Yamaha 94-96 TZ 125	BREMBO front brake master Cylinder with Lever 16X18	1		NEW
Yamaha 94-96 TZ 125	BREMBO Front Caliper Mount	1	Y005R	USED
Yamaha 94-96 TZ 125	Bushings	4	90380-08192	NEW
Yamaha 94-96 TZ 125	Case Gasket	2	4JT-15461-00	NEW
Yamaha 94-96 TZ 125	Circlip - Piston 5 Pack	2	93450-17129	NEW
Yamaha 94-96 TZ 125	Clip-on	2	4JT-26223-10	NEW
Yamaha 94-96 TZ 125	Clutch Housing(basket)	1	4JT-16310-00	USED
Yamaha 94-96 TZ 125	Clutch Lever w/ mount	1	214-83922-00-00	USED
Yamaha 94-96 TZ 125	Clutch Pressure Plate	1	37F-16351-00	USED
Yamaha 94-96 TZ 125	Clutch Push Lever Assembly	2	4JT-16380-10	USED
Yamaha 94-96 TZ 125	Clutch Thrust Plate	1	4JT-16184-00	USED
Yamaha 94-96 TZ 125	Collar, Wheel	1	4JT-25376-00	USED
Yamaha 94-96 TZ 125	Condenser, Smoothing	1	3TC-81965-0000	USED

Yamaha 94-96 TZ 125	Crank Case Assembly 96-97 TZ125	2	4JT-15100-02	USED
Yamaha 94-96 TZ 125	Crankcase Cover 2	2	4JT-15421-01	USED
Yamaha 94-96 TZ 125	Crankcase Lower NEW	1		NEW
Yamaha 94-96 TZ 125	Cranks Case Cover 1	2	4JT-15411-00	USED
Yamaha 94-96 TZ 125	Crankshaft & Rod	1	4JT-11400-02	USED
Yamaha 94-96 TZ 125	Cylinder Head	1	4JT-11111-00	USED
Yamaha 94-96 TZ 125	Dampner, Cush Drive (SET)	1	4JT-25364-00	NEW
Yamaha 94-96 TZ 125	Dash Foam Face	1		USED
Yamaha 94-96 TZ 125	Engine Lower 800 Miles	1		USED
Yamaha 94-96 TZ 125	ER Race Chain 415/120 Links	1		NEW
Yamaha 94-96 TZ 125	Exhaust O Ring	2	93210-42728	NEW
Yamaha 94-96 TZ 125	Exhaust Pipe	3	4JT-14610-50	USED
Yamaha 94-96 TZ 125	Flush DZUS Kit (3)	2	236-210	NEW
Yamaha 94-96 TZ 125	Footrest	1	4JT-27411-10	NEW
Yamaha 94-96 TZ 125	Fork, Shift 1	2	4JT-18511-00	USED
Yamaha 94-96 TZ 125	Fork, Shift 2	2	4JT-18521-00	USED
Yamaha 94-96 TZ 125	Frame	1	4JT-21110-200	USED
Yamaha 94-96 TZ 125	Front Brake Lever	1	4JT-83922-00-00	USED
Yamaha 94-96 TZ 125	Front Brake Pads	1		USED
Yamaha 94-96 TZ 125	Front Fender	1	4JT-21510-10	USED
Yamaha 94-96 TZ 125	Front Rotor	2	3XV-2581T-10	USED
Yamaha 94-96 TZ 125	Front Wheel & Bridgestone Tire	1	4JT-25168-00	SOLD
Yamaha 94-96 TZ 125	Fuel Tank, Cap & Valve	1	4JT-24110-00-36	USED
Yamaha 94-96 TZ 125	Gasket, Crank Case Cover 2	3	4JT-15461-00-00	NEW
Yamaha 94-96 TZ 125	Gear, 1st Wheel (29T)	2	4JT-17211-10	USED
Yamaha 94-96 TZ 125	Gear, 1st Wheel (30T)	3	4JT-17211-00	USED
Yamaha 94-96 TZ 125	Gear, 2nd Pinion (20T)	1		NEW
Yamaha 94-96 TZ 125	Gear, 2nd Pinion (21T)	5	4JT- 17121-00	USED
Yamaha 94-96 TZ 125	Gear, 2nd Wheel (30T)	1		NEW
Yamaha 94-96 TZ 125	Gear, 2nd Wheel (35T)	5	4JT-17221-00	USED
Yamaha 94-96 TZ 125	Gear, 3rd Wheel (23T)	2	4JT-17231-00	USED
Yamaha 94-96 TZ 125	Gear, 3rd Wheel (25)	1		NEW
Yamaha 94-96 TZ 125	Gear, 3rd Wheel (26T)	3	4JT-17231-10	USED
Yamaha 94-96 TZ 125	Gear, 3rd/4th Pinion (16/22T)	2	4JT-17131-00	USED
Yamaha 94-96 TZ 125	Gear, 3rd/4th Pinion (19/20T)	2		NEW
Yamaha 94-96 TZ 125	Gear, 3rd/4th Pinion (19/22T)	2	4JT-17131-10	USED
Yamaha 94-96 TZ 125	Gear, 4th Wheel (27T)	3	4JT-17241-10	USED
Yamaha 94-96 TZ 125	Gear, 4th Wheel (28T)	2	4JT-17241-00	USED
Yamaha 94-96 TZ 125	Gear, 4th Wheel (30T)	1		USED
Yamaha 94-96 TZ 125	Gear, 5th Pinion (21T)	4	4JT-17151-20	1 New
Yamaha 94-96 TZ 125	Gear, 5th Pinion (23T)	1	4JT-17151-10	USED
Yamaha 94-96 TZ 125	Gear, 5th Pinion (26T)	1		USED
Yamaha 94-96 TZ 125	Gear, 5th Wheel (23T)	1		USED
Yamaha 94-96 TZ 125	Gear, 5th Wheel (26T)	3	4JT-17251-10	USED
Yamaha 94-96 TZ 125	Gear, 6th Pinion (22T)	2	4JT-17161-20	USED
Yamaha 94-96 TZ 125	Gear, 6th Pinion (27T)	2	4JT-17161-11	USED
Yamaha 94-96 TZ 125	Gear, 6th Wheel (21T)	1		USED
Yamaha 94-96 TZ 125	Gear, 6th Wheel (23T)	2	4JT-17261-00	USED
Yamaha 94-96 TZ 125	Gear, 6th Wheel (29T)	2	4JT-17261-11	USED
Yamaha 94-96 TZ 125	Gear, Balance Weight	2	4JT-11531-00	1 New / 1 Used
Yamaha 94-96 TZ 125	Gear, Oil Pump Drive	1	4JT-13325-00	NEW
Yamaha 94-96 TZ 125	Grand Prix Chain - 120 Links	1		USED
Yamaha 94-96 TZ 125	Grommet, Fuel Tank	2	90480-18495	NEW
Yamaha 94-96 TZ 125	Head Bolt Crush Washer 5 Pack	2	90430-06166	NEW
Yamaha 94-96 TZ 125	Head O-Ring - Small	4	93210-88696	NEW
Yamaha 94-96 TZ 125	Ignition Coils	2	4DP-82310-00	USED

Yamaha 94-96 TZ 125	Intake Gasket	3	4JT-13621-00-00	NEW
Yamaha 94-96 TZ 125	Intake Manifold	1	4JT-13555-00-00	USED
Yamaha 94-96 TZ 125	Key, Woodruff	1	90280-04051	NEW
Yamaha 94-96 TZ 125	LH Front Fork	2	4JT-23102-20	USED
Yamaha 94-96 TZ 125	Locating Dampners 2	3	1RK-24182-00	NEW
Yamaha 94-96 TZ 125	Lock Washer, Sprocket	2	90215-21239	NEW
Yamaha 94-96 TZ 125	Lower Fairing	3		USED
Yamaha 94-96 TZ 125	Magneto	2	03700-3302	USED
Yamaha 94-96 TZ 125	Magneto Puller	1	08-0026	USED
Yamaha 94-96 TZ 125	Main Frame SR#688	1	4JT-21110-20	Needs Repair
Yamaha 94-96 TZ 125	Mukuni Carbs w/ Power Valve	1	4JT-14101-20	USED
Yamaha 94-96 TZ 125	NGK Spark Plug	1	R6385-105P	NEW
Yamaha 94-96 TZ 125	Nut	4	4AO-28364-00-00	NEW
Yamaha 94-96 TZ 125	Nut, Flange 4 Pack	2	90179-08491	NEW
Yamaha 94-96 TZ 125	O Ring	4	93210-48364	NEW
Yamaha 94-96 TZ 125	O Ring	4	93210-06632	NEW
Yamaha 94-96 TZ 125	O Ring	2	93210-34633	NEW
Yamaha 94-96 TZ 125	O Ring	2	93210-14515	NEW
Yamaha 94-96 TZ 125	O Ring	2	93210-16314	NEW
Yamaha 94-96 TZ 125	O Ring Small for head	4	93210-63442	NEW
Yamaha 94-96 TZ 125	O Seal	4	93104-08040	NEW
Yamaha 94-96 TZ 125	Oil Pipe, Delivery 1	2	4JT-13161-00	USED
Yamaha 94-96 TZ 125	Oil Pump	1	4JT-13300-01	USED
Yamaha 94-96 TZ 125	Oil Pump Assembly w/o Gear	2	4JT-13300-00	USED
Yamaha 94-96 TZ 125	Oil Seal	2	93101-45091	NEW
Yamaha 94-96 TZ 125	Oil Seal	1	93103-32177	NEW
Yamaha 94-96 TZ 125	Oil Seal	1	93102-26042	NEW
Yamaha 94-96 TZ 125	Oil Tank	1	3YL-21751-00	USED
Yamaha 94-96 TZ 125	Panel	2	4JT-2836A-00-00	USED
Yamaha 94-96 TZ 125	Pin, Crank	1	4JT-11681-00	NEW
Yamaha 94-96 TZ 125	Pin, Dowel	2	99530-10014	NEW
Yamaha 94-96 TZ 125	Pin, Piston 90-99	2	137-11633-10	NEW
Yamaha 94-96 TZ 125	Pin. Dowel	1	99510-10114	NEW
Yamaha 94-96 TZ 125	Piston	2	4DP-11631-02-BO	USED
Yamaha 94-96 TZ 125	Piston Ring	2	1RK-11611-01	USED
Yamaha 94-96 TZ 125	Plug Cap Assy.	2	8DG-82370-00	1 New / 1 Used
Yamaha 94-96 TZ 125	Power Valve	1	3YL-1131A-00	USED
Yamaha 94-96 TZ 125	Power Valve Cover	1		USED
Yamaha 94-96 TZ 125	Power Valve Pulley Shaft 1	1	4DP-1132E-00-00	USED
Yamaha 94-96 TZ 125	Primary Drive Gear	2	4JT-16151-01	USED
Yamaha 94-96 TZ 125	Pump Cover Gasket	7	22F-13329-01-00	NEW
Yamaha 94-96 TZ 125	Radiator with cap	1	4JT-12461-10	USED
Yamaha 94-96 TZ 125	Rear Brake Assembly	1		USED
Yamaha 94-96 TZ 125	Rear Shock	2	4JT-22210-71	USED
Yamaha 94-96 TZ 125	Rear Shock Spring	1		USED
Yamaha 94-96 TZ 125	Rear Wheel Stand	1		USED
Yamaha 94-96 TZ 125	Rear Wheel, Bridgestone	1	4JT-25338-00	SOLD
Yamaha 94-96 TZ 125	Rear set	3	4JT-27412-10	USED
Yamaha 94-96 TZ 125	Rear set Plate - Brake Side	1	4JT-27445-00	USED
Yamaha 94-96 TZ 125	Reed Valve 2 (Reeds)	2	4JT-13614-00	USED
Yamaha 94-96 TZ 125	Reed Valve Assy. w/ reeds	1	4JT-13610-00-00	USED
Yamaha 94-96 TZ 125	Reeds	2	3XV-13613-01	NEW
Yamaha 94-96 TZ 125	Regulator/Rectifier	1	1JK-81960-A1-00	USED
Yamaha 94-96 TZ 125	Relay Arm & Connecting Rods	2	4JT-2217A-00	USED
Yamaha 94-96 TZ 125	Reservoir	1		USED
Yamaha 94-96 TZ 125	RH Front Fork	2		USED

Yamaha 94-96 TZ 125	ROD, Connecting	1	4JT-11651-00	USED
Yamaha 94-96 TZ 125	Rod, Push 1	1	4JT-16356-00	USED
Yamaha 94-96 TZ 125	Rod, Push 2	2	4JT- 16357-00	USED
Yamaha 94-96 TZ 125	Servo Motor EX	1	4JT-85820-0000	USED
Yamaha 94-96 TZ 125	Set of aftermarket foot pegs	1		NEW
Yamaha 94-96 TZ 125	Set of blue anodized Clip-on bars	2		NEW
Yamaha 94-96 TZ 125	Chicken Hawk Tire Warmers	1		USED
Yamaha 94-96 TZ 125	Shift Lever	1		NEW
Yamaha 94-96 TZ 125	Shift Seal	1	93109-12012	NEW
Yamaha 94-96 TZ 125	Silencer - Carbon	2	4JT-14753-10-C	1 New Pare
Yamaha 94-96 TZ 125	Silencer Steel	2	4JT-14753-10-S	USED
Yamaha 94-96 TZ 125	Springs, Clutch	16	90501-20361	USED
Yamaha 94-96 TZ 125	Spring, Torsion	2	90508-235A8	USED
Yamaha 94-96 TZ 125	Sprocket, Drive	2	4JT-25438-10	USED
Yamaha 94-96 TZ 125	Sprocket, Drive (16T)	1	938AA-16198	USED
Yamaha 94-96 TZ 125	Sprocket, Drive (17T)	1	938AA-17196	USED
Yamaha 94-96 TZ 125	Sprocket, Drive (18T)	3	938AA-18199	USED
Yamaha 94-96 TZ 125	Sprocket, Drive (35T)	1	4JT-25435-10	USED
Yamaha 94-96 TZ 125	Sprocket, Drive (36T)	1	4JT-25436-10	USED
Yamaha 94-96 TZ 125	Sprocket, Drive (37T)	2	4JT-25437-10	USED
Yamaha 94-96 TZ 125	Sprocket, Drive (39T)	5	4JT-25439-10	USED
Yamaha 94-96 TZ 125	Sprocket, Drive (40T)	1		USED
Yamaha 94-96 TZ 125	Sprocket, Drive (43T) AFAM	1		USED
Yamaha 94-96 TZ 125	Stator	2		USED
Yamaha 94-96 TZ 125	Stay	1	4JT-28356-00	USED
Yamaha 94-96 TZ 125	Stay 3	2	3YL-28358-00-00	NEW
Yamaha 94-96 TZ 125	Steering Dampner	2	4JT-23490-11	USED
Yamaha 94-96 TZ 125	Steering Dampner Stay	1	4JT-23495-00	USED
Yamaha 94-96 TZ 125	Stopper Lever Assembly	2	4JT-18140-11	NEW
Yamaha 94-96 TZ 125	Strainer, Oil	2	3XV-13411-00	USED
Yamaha 94-96 TZ 125	Strainer, Oil 2	2	3XV-13421-00	USED
Yamaha 94-96 TZ 125	Sub frame	2	4JT-21190-00	1 New / 1 Used
Yamaha 94-96 TZ 125	Swing arm with bolt	2	4JT-22110-10-00	USED
Yamaha 94-96 TZ 125	Tachometer	1	3YL-83540-00	USED
Yamaha 94-96 TZ 125	Tail Section	2	4JT-247101-11	NEW
Yamaha 94-96 TZ 125	Tail Section w/ seat foam	1	4JT-247101-11-U	USED
Yamaha 94-96 TZ 125	Throttle Grip	2	47X-26241-00	NEW
Yamaha 94-96 TZ 125	Trans Crank Case 3	2	4JT-15131-01	USED
Yamaha 94-96 TZ 125	Trans Fork, Shift 3	2	4JT-18513-01	USED
Yamaha 94-96 TZ 125	Trans Shift Cam Assembly	2	4JT-18540-10	USED
Yamaha 94-96 TZ 125	Trans Shift Shaft Assembly	1	4JT-18101-00	USED
Yamaha 94-96 TZ 125	Triple Tree	2	4jt-23435-00	USED
Yamaha 94-96 TZ 125	Upper Fairing	3	4JT-28350-20	USED
Yamaha 94-96 TZ 125	Washer for Head Bolt	1	90430-12202-00	NEW
Yamaha 94-96 TZ 125	Washer, Lock	2	90215-14204	NEW
Yamaha 94-96 TZ 125	Water Pump Gasket	3	4JT-12428-00-00	NEW
Yamaha 94-96 TZ 125	Water Pump Housing	2	4JT-12422-00-00	USED
Yamaha 94-96 TZ 125	Water Pump Impeller	3	4JT-12450-00	1 NEW
Yamaha 94-96 TZ 125	Water Pump Seal	1	93103-12119	NEW
Yamaha 94-96 TZ 125	Water Temp gauge	1	4JT-83590-01	USED
Yamaha 94-96 TZ 125	Windshield Mounting Screws	1	101-101	NEW
Yamaha 94-96 TZ 125	Windshield Mounting Screws	1	101-128	NEW
Yamaha 94-96 TZ 125	Yellow Vinyl Race #'s Background	1		NEW
Yamaha 94-96 TZ 125	Zero Gravity Windscreen	1	22-563-01	NEW